

LIGHT CUBE WALLCOVERING HANGING INSTRUCTIONS type-E

BEFORE YOU START...

- Carefully inspect all materials and make certain that the pattern and colour are exactly as ordered.
- No claims will be accepted for cut/installed material, beyond the installation of 1 roll, or after 14 days of delivery.
- You may find certain irregularity, which are the characteristics of this natural product.

SURFACE PREPARATION

- Remove all existing wallcovering, backing paper, paint, and all surface contaminations, ensure the surface is smooth and dry.
- Make sure to match the colour to the wall when using putty.
- Apply primer/sealer and allow to dry.

ADHESIVE

- We recommend using starch based, ready mixed wallcovering adhesive.

HANGING

- Paste the back of the wallcovering, book for 5-15minutes to let adhesive penetrate the material.
- Do not crease the paper when folding length, and do not pile after pasting.
- Work quickly using a spatula or a brush, and gently smooth the paper onto the wall.
- Joints should be tightly butted. Do not use the seam roller, as this will damage the surface.
- Avoid adhesive to get onto the surface of any wallcovering. Immediately wipe off any excessive paste with soft damp cloth and then with a dry cloth. Do not rub or use sponge as it may damage the surface of wallcovering.