

# **LIGHT CUBE WALLCOVERING HANGING INSTRUCTIONS type-G**

## **BEFORE YOU START...**

- Carefully inspect all materials and make certain that the pattern and colour are exactly as ordered.
- No claims will be accepted for cut/installed material, beyond the installation of 1 roll, or after 14 days of delivery.
- Wallcoverings may have certain irregularity, which are the characteristics of this delicate natural handmade product and not defects.

## **SURFACE PREPARATION**

- Remove all existing wallcovering, backing paper, paint, and all surface contaminations, ensure the surface is smooth and dry.
- Make sure to match the colour to the wall when using putty.
- Prepare wall with oil-based alkali-resisting primer to mirror-smoothness and allow to dry.
- Never hang on non-absorbent surface such as iron plate.

## **ADHESIVE**

- We recommend using starch based, ready mixed wallcovering adhesive.

## **HANGING**

- Trim the side edges with a very sharp razor blade. If you choose to overlap and trim joint, ensure to use protective plastic strip to prevent damage to the substrate and wall surface.
- Apply moderate amount of adhesive and spread evenly on the back of the wallcovering, and book for 5 minutes before hanging.
- Do not fold or pile after pasting.
- Work quickly using soft brush, and gently smooth the paper onto the wall.
- Do not use seam roller directly on the surface of wallcovering. Place a strip of material in between the roller and wallcovering to avoid damage.
- Avoid adhesive to get onto the surface of any wallcovering. Immediately wipe off any excessive paste with soft damp cloth and then with a dry cloth. Do not rub or use sponge as it may damage the surface of wallcovering.
- Avoid direct or strongly reflected sunlight as it may cause fading or colour change. We do not guarantee against fading and colour change, as this is also the nature of the product.