

# **LIGHT CUBE WALLCOVERING HANGING INSTRUCTIONS type-I**

## **BEFORE YOU START...**

- Carefully inspect all materials and make certain that the pattern and colour are exactly as ordered.
- No claims will be accepted for cut/installed material, beyond the installation of 1 roll, or after 14 days of delivery.
- You may find variations in weaving and colour effects, which are considered characteristics/part of the beauty of such products, and are not defects.

## **SURFACE PREPARATION**

- Remove all existing wallcovering, backing paper, paint, and all surface contaminations, ensure the surface is smooth and dry.
- Make sure to match the colour to the wall when using putty.
- Apply primer/sealer and allow to dry.

## **ADHESIVE**

- We recommend using starch based, ready mixed wallcovering adhesive.

## **HANGING**

- Paste the back of the wallcovering, book for 5-15minutes to let adhesive penetrate the material.
- Do not crease the paper when folding length, and do not pile after pasting.
- Work quickly using a soft brush in vertical direction only, and gently smooth the paper onto the wall.
- Use protective plastic strip to prevent damage to the substrate and wall surface and double-cut to match the pattern. Gently use the seam roller to finish off the joint. Avoid excessive seam rolling, as this may cause damage.
- Avoid adhesive to get onto the surface of any wallcovering. Immediately wipe off any excessive paste with soft damp cloth and then with a dry cloth. Do not rub or use sponge as it may damage the surface of wallcovering.